

Drive Through Berm Installation Instructions

Step 1:



Prepare the berm for setup by unrolling and unfolding the berm so that it lies flat on the ground. Aluminum angle sides should be folded in with the pocket showing.

Step 2:



Set aluminum angle L brackets along side walls next to their matching pockets. Angles will feature a 90° angle that should create the wall height on the berm.

Step 3:



Slide the aluminum angles into pockets located on the walls of the berm so that the top portion of the angle fits into the pocket, while the bottom sits underneath the berm.

Step 4 (Optional):



Once all the angles have been inserted, sit the walls of berm up to complete your containment area.

Step 5:



Install or place equipment into the containment area. If a spill occurs, foam wall ends should rise up as the area fills with liquid.

Optional Items:

- Ground Mat
- Tread Guards
- Wear Pads
- Drains (placed on the low point of the berm)