

Taurus Runoff Filtration

Installation Guide

Step 1: Lay out and assemble all required items, including caulk, angle brackets, masonry bit, tapcons and a warning flag



Step 2: Place the filter bag pockets (2) over the top of the angle brackets.



Step 3: Slide pockets over the brackets until the bottom of the pocket rests on top of the bracket.



Step 4: On one of the angle brackets, drill the concrete through the pre-drilled holes on the bracket. This should be done using a masonry bit that is properly sized for the tapcons you are using.



Taurus Runoff Filtration

Installation Guide

Step 5: Before fastening the brackets with tapcons, apply a bead of caulk (provided) under the bracket.



Step 6: Fasten the first aluminum angle bracket with tapcons.



Step 7: Pull the bag taught and align the second bracket. Repeat steps 4-6. Once complete, both brackets should be fully secured to the concrete.



Step 8: Place a bead of caulk under the front edge of the panel (shown below). Make sure the area is dry and free of any debris.



GEI
WORKS

Taurus Runoff Filtration

Installation Guide

Step 9: Using the provided roller, roll the front edge flat. Smooth and remove excess buildup.



Step 10: Finish installation by placing a warning flag on the unit.



For more complete information on GEI Works products and solutions, visit us on the Web at www.geiworks.com.

© 2015 GEI Works
All rights reserved
GEI Works terms and conditions apply.

All photos are representatives only. Actual Product may differ than featured.

Materials and specifications are subject to change without notice. Featured products in photos may include additional equipment or accessories. See your GEI Works Dealer for available options.

GEI Works, Taurus, geiworks.com, their respective logos, product identity used herein, are trademarks of GEI Works and may not be used without permission.



GEI
WORKS